# INDEX

# INDEX

Note to the Reader: Throughout this index **boldfaced** page numbers indicate primary discussions of a topic. *Italicized* page numbers indicate illustrations.

#### Α

abbreviations commands, 35 metric, 14 accuracy of temporary dimensions, 75–76, 76 activating views, 620, 620 ADA (Americans with Disabilities Act) compliance, 472-474, 473-474, 481-482 Add Parameter(s) To Label button, 634, 634 Add Point button, 311, 312, 314, 316 Add Split Line button, 311, 313 Add To Quick Access Toolbar option, 6, 6 Align tool locking alignments, 193-194, 193-194 overview, 188-193 aligned dimensions angles, 220-222, 221 overriding precision, 223-225, 223-225 overview, 214-216, 214-216 picking points for, 217-219, 217-220 witness lines, 222-223, 222 Aligned To Selected Levels option, 206 landings, 488 railings, 485, 485 windows, 210

alignment floor plans, 210, 211 locking, 193-194, 193-194 objects, 188-193, 189-192 railing ends, 476, 476-477 textual notations, 571 winding staircases, 488 alternate floor materials separating, 457-459, 458 splitting, 283–286, 283–285 tile, 459-461, 459-461 Americans with Disabilities Act (ADA) compliance, 472–474, 473–474, 481 - 482Analyze tab, 655 angle objects, 557-558, 558-559 angles aligned dimensions, 214, 220-222, 221 arrays, 178, 178 ceiling grids, 412, 413 grids, 358-359 rotation, 175 walls, 72, 73, 75 Angular Dimension Snap Increments option, 75 angular dimensions, 227–228, 227–228

Annotate tab alignment, 234, 234, 240, 242 arc length, 231 color fill, 662 Detail Component option, 532, 554, 557 detail groups, 583 detail lines doors, 487-488, 487 line size, 566, 566 offsets. 573 roofs, 312, 314 trim, 577 diameters, 229, 230 dimensions aligned, 214, 214, 217, 242 linear, 225 radial. 229 insulation, 585, 585 lag bolts, 559 leader text, 250 leader type, 250, 251 masking regions, 534, 534 match lines, 607 repeating details, 536, 537, 538, 540 revision clouds, 626, 628 text, 247, 248 textual notations, 570 wall ties, 560 Annotation Objects tab, 606, 606 annotations. See also text callouts, 145 crop regions, 601–603, 602–603 elevations, 161-163, 162

match lines, 606, 606 placing, 247-250, 248-249 appearance levels, 111 match lines, 605–606, 606–607 Appears In Sheet List option, 636, 637 Application icon, 3 Apply View Template dialog, 609, 609 arc length dimensions, 230–232, 231–232 Architectural Template option, 3 Architecture tab area plans, 659 ceilings, 408, 419 columns, 368, 370 components bathrooms, 438 light fixtures, 432, 432 openings, 98-99, 98 doors adding, 90, 90 alignment, 192 hosted families, 39 openings, 98-99 families, 95 floors, 256, 256, 266, 501 grids, 354, 358-359, 363 landings, 512 levels, 108, 108, 296 line drawing, 357 Model Line option, 592 railings, 480, 498, 525 raised panels, 517–518 ramps, 520-521 reference planes, 47, 47

adding, 171 linear arrays, 180 roofs, 340 stairs, 473 walls, 71-72 Ribbon, 4, 4 roof extrusions, 341, 341 roofs, 304, 305, 321 room separators, 658, 658 rooms, 642-643 Set option, 591, 591 shafts, 298, 298 soffits, 426 stairs, 465, 466 custom, 507 reference planes, 473 winding, 493 walls, 7 interior, 58, 71-72 reference planes, 340 windows, 100, 100, 181, 189 arcs filled regions, 556 interior partitions, 67, 67 landings, 468-469, 468 mortar joints, 546 railings, 483, 483 roof extrusions, 343, 344 roofs, 592-593, 592 winding staircases, 488-492, 488-491, 494 Area Boundary button, 659, 659 area plans, 659–662, 659–662 arrays linear, 180-185, 180-184

radial, 175–180, *176–179* winding staircase lines, **491–492**, *491* arrows flip, **267**, *267* leaders, 251, *252* slope, 334–335, *334–335* At Grid Intersection tab, 374 attaching walls to roofs extrusions, 345, *345–346* pitched, **328**, *329* sloping, 337–338, *337* Auto Dimension Options dialog, 215–216, *215* AutoCAD, files from, **589–590** Automatic Beam System button, 381, *381* 

#### B

background filled regions, 545, 545 sheets, 13 Baluster Per Tread setting, 505 balusters placing, 475, 475 railing systems, 505-506, 505 base units, 452-454, 453-454 bathroom plumbing fixtures, 435–442, 436 - 442beam systems, 380-383, 381-382 BIM (Building Information Modeling) benefits, 21 drafting, 490 file types, 36-37fully integrated models, 31 levels, 106 overview, 1

blank drafting views 2D and 3D lines, 590-593, 591-592 creating, 572-581, 573-580 detail groups, 581-586, 582-586 importing AutoCAD files into, 589-590 sections for views, 587-588, 588 blocking detail lines, 567-568, 568 filled regions, 562-564, 563 bolts, 559, 560 borders crop regions, 139 plan regions, 418 boundaries ceilings, 423-425, 424 filled regions, 543, 543 Rise/Run function, 467–468, 467–468 structures, 260 boxes, selection, 18, 18 bracing, 383-387, 384-387 break lines, 532-535, 533, 535 Bring To Front button, 535, 535, 540 Browser Organization dialog, 405, 405 bubbles black, 111 callouts, 144 columns, 355, 355-356 displaying, 117, 118 elevations, 158 grids, 355-362, 356, 360, 362, 366, 436 hiding, 117 levels, 107-108 roofs, 114

sections, 129, 623 walls, 363–364, *364* Building Information Modeling (BIM) benefits, 21 drafting, 490 file types, **36–37** fully integrated models, 31 levels, 106 overview, 1 building sections, **121** adding, **122–129**, *122–129* modifications, **129–134**, *130–135* 

## С

cabinets, 450-457, 453-455 CAD, files from, 589–590 callouts creating, 143-148, 143-148 lavatories, 147-148, 147-148 cameras and camera views, 149 adding, 149-151, 149-150 modifications, 151-152, 151-152 Cancel Edit Mode option, 195 casework, 447-457, 447-457 ceilings, 407 creating, 407-410, 408-410 custom, 419-422, 419-422 in empty spaces, 423, 423 grids, 412-413, 412-413 light fixtures, 431–434, 432–435 lighting, 443, 443 openings, 423-425, 424-425 plan regions, 417-419, 417-418

properties, 414-417, 414-416 soffits, 426-430, 426-430 summary, 462 centerlines beam, 380 doors, 194 dotted, 170 in mirroring, 95 offsets, 57, 57 walls, 235, 277, 277 windows, 190, 231 Chain option, 12, 50 chairs, adding, 448, 448 Choose Space Type and Color Scheme dialog, 656, 656, 662 Clean All Wall Joins option, 83 Clean Same Type Wall Joins option, 83 cleaning up floor slab sketches, 269–271. 269-270 clipboard Copy/Paste tool, 205–208, 206–207 doors. 488 floors, 279, 279 railings, 484–485, 484 Close Hidden Windows option, 34 closing hidden windows, 34 views, 34, 34 clouds, revision, 625-628, 626-628 Coarse detail level, 25 color filled regions, 548, 548 schemes, 656-657, 656-657

Color dialog, 548, 548 Color Fill Legend button, 655, 656 Color Fill Legends tab, 657, 662 color-fill plans, 655-657, 656-657 columns adding, 368-375, 368-375 framing, 376-380, 376-380 grids, 354-355, 354-355, 359, 360 piers, 400-402, 400-402 commands, typing, 35, 35 Constrain option copying, 169 moves, 167 constraints dimensions for, 237-241, 238-241 levels, 115, 116, 121 Copy command, 169–171, 169–170 Copy/Paste Aligned feature, 279, 279 Copy/Paste tool, 205-208, 206-207 Copy To Clipboard button, 279, 279 copying floor layers, 279, 279 in floor plans, 210, 211 light fixtures, 433–434, 433, 435 with offset, 203-204, 204-205 with rotating, 175 walls, 169-171, 169-170 corridors callouts, 143-145, 143-145 camera views, 149, 150 dimensions, 227-228, 227-228 doors, 96, 98 elevations, 153

grids, 359-361, 360-361 lighting, 445-446, 446 linear dimensions, 225-226, 226 roof. See pitched roofs walls, 68-69, 68-69, 71-72, 73-74 countertops, 450-451, 451 cover sheets, 631-636, 631-637 Create Boundary tab, 286, 459 Create Detail Group dialog, 581 Create Extrusion Roof Profile tab, 343 Create Floor Boundary tab Finish Edit Mode option, 278, 398 pick lines, 266 Pick Walls option, 270 slabs, 266 Create Ramp tab, 524 Create Revision Cloud Sketch tab, 626 Create Roof Footprint tab Finish Edit Mode option, 327 perimeters, 304-306 trimming, 323 Create Shaft Opening Sketch tab, 298–299 Create Similar option, 21, 22 Create Stair tab, 465, 466, 471 Create tab families, 551 filled regions, 547, 547 groups, 581, 582 labels, 633, 633 lines, 546, 556 **Create View Template From View** option, 609 credenzas, 447, 448

crop regions callouts, 144–147, *145–146* dependent views, **598–602**, *599–603* detail sections, **139–140**, *139–140* hiding, 621 stretching, 620–621, *620* crossing windows, 18, *18* Ctrl key for unselecting items, 65 custom ceilings, **419–422**, *419–422* custom stairs creating, **507–511**, *507*, *509–511* goosenecks, **513–520**, *514–520* landings, **512**, *512–513* cut profiles, **87–89**, *87–89* 

#### D

Datum panel grids, 354, 354, 356 levels, 108, 108 deactivating views, 621 Default 3D View button, 115, 115 DefaultMetric.rte file, 3 Delete Inner Segment option, 77, 78 dependent views creating, 597–598, 598 crop regions, 598–603, 599–603 desks, 447, 448 detail groups, 581-586, 582-586 Detail Groups tab, 585 Detail Items tab, 535–536, 535, 562 Detail Level control, 25, 25

detail sections creating, 138–139, 138 crop regions, 139–140, 139–140 splitting section segments, 140–143, 141–142 detailing, 529 blank drafting views 2D and 3D lines, 590-593, 591-592 creating, 572–581, 573–580 detail groups, 581-586, 582-586 importing AutoCAD files into, 589-590 sections for views, 587-588, 588 drafting on top of, 532 components, 541-542, 541 detail lines. 566–568. 566–568 filled regions. See filled regions masking regions, 534–536, 534–536 predefined detail components, 532, 533 repeating details, 536-541, 537-541 line weights, 529–531, 530–531 notes, 570–572, 571–572 summary, 593 Dimension Text dialog, 245-246, 245-246 dimensions, 213-214 aligned angles, 220-222, 221 overriding precision, 223-225. 223-225 overview, 214-216, 214-216 picking points for, 217-219, 217-220 witness lines, 222–223, 222 angular, 227–228, 227–228 arc length, 230-232, 231-232

as layout tool, 232–237, 233–237 constraining models, 237–241, 238–241 moving objects, 241–244, 242–244 text overrides, 244–246, 245–247 linear, 225–227, 226 locking, 240–241, 240–241 radial, 228-230, 229-230 stairs, 509, 509 summary, 254 temporary. See temporary dimensions disallowing wall joins, 84-89, 85-89 Disjoin option, 167 doors, 90 adding, 90-94, 90-94 alignments, 193-194, 193-194 corridor, 96, 98 families, 95-96, 95-97 inserting, 39 lavatory, 96, 97 tags, 90, 95 wall openings, 98-99, 98-99 winding staircase, 487–488 wrapping materials, 92, 92 dormers, 347-352, 348-351 drafting on top of detail, 532 components, 541-542, 541 detail lines, 566–568, 566–568 filled regions. See filled regions masking regions, 534–536, 534–536 predefined detail components, 532, 533 repeating details, 536–541, 537-541

drafting views 2D and 3D lines, **590–593**, *591–592* creating, **572–581**, *573–580* detail groups, **581–586**, *582–586* importing AutoCAD files into, **589–590** sections for views, **587–588**, *588* drains flat roofs, **310–311** pitching floors to, **291–294**, *291–295* Draw panel for sketch options, 12 Draw tab for lines, **658** drawing detail lines, **566–568**, *566–568* Duplicate button, 10 duplicate views, **595–597**, *596* 

#### E

Edit Assembly dialog floors layers, 273-276, 274, 276 materials, 284 slabs, 260-261, 260 roofs extrusions, 343, 343 flat, 308, 308-309, 310 pitched, 320, 320 Edit Baluster Placement dialog, 475, 476, 505.505 Edit Boundary tab, 282 Edit Color Scheme dialog, 657 edit commands, 166 Copy, 169-171, 169-170 Move, 166–168, 167–168 Rotate, 171–175, 171–175

Edit Footprint tab, 324, 348 Edit Group toolbar, 586, 586 Edit Label dialog rooms, 652, 652 tags, 634, 634 Edit Profile tab Finish Edit Mode option, 133, 198, *199* pick lines, 197 splitting elements, 195, 195 walls. 130 Edit Type button, 10, 11, 92, 92, 98 Edit Wall Joins command, 79 elbows for grids, 361–362, 362 elements, splitting, 194–198, 195-199 elevations annotation properties, 161–163, 162 creating, 152–156, 153–155 interior, 156–159, 156–159 kitchen items, 452–454, 453 Project Browser, 32–33, 33 properties, 159-161, 160-161 roof extrusions, 339, 340 elevator shafts footing slabs, 396-398, 397, 399 laying out, 58–60, 59 mirroring, 64–65, 65 openings, 296-300, 296-301 empty spaces, ceilings in, 423, 423 "Ends of the sketched loop don't lie on the boundary of the face being modified" option, 89 entertainment center, 448

EQ button aligned dimensions, 219, *219* constraining objects, 238 wall dimensions, 237, *237* existing geometry, building on, 21–24, *22–24* Extend Into Wall core option, 265 extending railings, 474–479, 474–479 Exterior - Brick And CMU On MTL. Stud option, 7, *8*, 14 exterior walls, 45–46, *46* extrusions, roofs, 338–347, *339–347* 

#### F

facade anchoring, 557, 558 families doors, 95-96, 95-97 hosted, 38-40, 39-41 loading, 95-96, 95-97 Revit family files, 42–43, 42 Revit template files, 41–42, 42 stairs and railings, 501–502, 501–502 system, 37–38 feet. 169 fields in schedules, 653, 653 Fields tab, 653, 653 File Save Options dialog, settings, 36, 37 file types. See families files printing to, 637 saving, 36–37, 36–37 template, 41-42, 42 Fill Patterns dialog, 548, 548

filled regions angle object, 557–558, 558–559 blank drafting views, 579-580, 579 blocking, 562–564, 563 façade anchoring, 557, 558 mortar joints, 546, 547 overview, 542-546, 542-546 repeated detail, 554-556, 555-557 shading, 547–552, 547–553 wall ties, 560-562, 561-562 fillers for base cabinets, 454–455, 455 Filter dialog, 284, 284 filters for floor materials, 284, 284 Fine detail level. 25 Finish Edit Mode button command completion, 89, 89 warning, 200 Finish Face: Exterior option, 12, 12 Fit To Page button, 639 fixtures light, 431-434, 432-435 plumbing, 435-442, 436-442 flat roofs creating, 307–310, 308–309 drains, 310–311 overview, 304-307, 305-306 tapering, 310-319, 311-319 flip arrows, 267, 267 flip grips, 123–124, 124 floor plans, 208–212, 209–211 floors, 255 floor slabs, 255–256 corridor, 266-268, 266-268 creating, 256-261, 256-261

picking walls, 262-264, 262-265 trimming, 269-271, 269-270 lavers, 271 adding, 273-282, 274-282 materials, 272-273, 272 materials alternate, 457-461, 457-461 splitting, 283-291, 283-290 pitching to drains, 291-294, 291-295 separating, 457-459, 458 shaft openings, 296-300, 296-301 summary, 302 fonts, 253 footings adding, 393-396, 394-395 piers, 400-402, 400-402 structural slabs, 396-400, 396-399 footprints flat roofs creating, 307-310, 308-309 drains, 310-311 overview, 304-307, 305-306 tapering, 310-319, 311-319 pitched roofs. See pitched roofs formatting aligned dimensions, 224, 225 foundation systems, 387-393, 388-393 fractions, 169 framing beam systems, 380-383, 381-382 bracing, 383-387, 384-387 working with, 376-380, 376-380 furniture kitchen, 450-457, 451-457

office, 447–449, *447–448* perspective view, 449, *449–450* 

#### G

gable ends, 322, 323 gaps sections, 124, 125 with splits, 197–198 walls, 54, 69 Gaps in Segments button, 124 Generic Models tab, 478 ghosted objects, 415 Go To Primary View option, 599 goosenecks for stairs, 513-520, 514-520 grab bars, 439, 440 Graphic Display Options dialog, 446, 446 Graphics tab floor slabs, 260, 261 materials, 428, 429 patterns, 564 grids, 353–354 ceilings, 412-413, 412-413 columns, 372-374, 373-374 elbows, 361-362, 362 placing, 354-361, 354-361 radial, 366-368, 367 vertical, 363-366, 363-366 visibility, 378 grips aligned dimensions, 220-221 building sections, 123-124, 125, 132, 133 callouts, 144, 144-145 crop regions, 139, 139

elbows, 361, elevations, 155, flip, 123–124, leader text, 244, levels, 107–108, *107*, 113, *113*, 118, match lines, 608 reference planes, 48, sheets, 613 stretch lines, 198, temporary dimensions, 70 text, 250, 253 views, 601, witness lines, 222–223, groups, detail, 581–586, *582–586* guide grids for sheets, 613,

#### Η

height of columns, 370, *370* hidden windows, closing, 34 Hide Bubble option, 117 Hide Crop Region option, 621 Hide Unreferenced View Tags option, 639 hiding crop regions, 621 hosted families, 38–40, *39–41*, 90, *91* 

#### I

Import dialog, 589 importing AutoCAD files into drafting views, 589–590 inches, 169 Insert tab blocking, 560 CAD files, 589

casework, 447, 450 families, 437 fixtures, 436 lighting, 443 plumbing, 440 railings, 503 rod family, 383 sconces, 445 wall ties, 561 instances, Ribbon, 9, 10 insulation, 308, 310, 585-586, 586 interface, 2-3, 3-4 existing geometry, 21-24, 22-24 modifying and mirroring, 19–21, 19–21 object selection, 17-18, 17-18 Ribbon. See Ribbon summary, 43 view control and object display, 24–31, 24 - 31view window, 13-17, 14-16 workflow, 4–5, 4–5 interior design, 435 alternate floor materials, 457-461, 457-461 casework and furniture kitchen, 450-457, 451-457 office, 447-449, 447-448 perspective view, 449, 449-450 parabolic troffers, 443-447, 443-446 plumbing fixtures, 435-442, 436-442 summary, 462 interior elevations, 156–159, 156–159 interior partitions, 66-68, 66-69

interior walls adding, 58–60, 59 temporary dimensions. See temporary dimensions intersections columns at, 374, 375 wall joins, 80–82, 81–82 Invalid Dimension Value message, 245, 245

# J

jogs, 140–143, *141–142* joins, wall disallowing, 84–89, *85–89* displaying, 82–83, *83–84* editing, **79–82**, *79–82* joints, mortar, **546**, *547* justification, walls, 12

#### Κ

keyboard shortcuts, 35, 35

#### L

labels, sheets, 634, 634 lag bolts, 559, 560 landings boundaries, 467–468, 468 custom, 512, 512–513 railings, 479–483, 480–482, 515–516, 516 winding staircases, 486–487, 487, 498– 501, 498-501lavatories adding, 70, 70–71 callouts, 147–148, 147–148

doors, 96, 97 pitching floors to drains, 291–294, 291-295 plumbing fixtures, 435-442, 436-442 layers for floors, 271 adding, 273–282, 274–282 materials, 272-273, 272 layout tool, dimensions as, 232-237, 233-237 constraining models, 237–241, 238 - 241moving objects, 241-244, 242-244 text overrides, 244-246, 245-247 leaders text, 244, 244, 250-251, 250 textual notations, 571, 571 type, 251, 251-252 legends, area, 662, 662 Length Dimension Snap Increment option, 75 levels adding, 108–110, 108–110 adjustments, 114-122, 114-122 composition, 110-114, 111-114 constraints, 115, 116, 121 creating, 105–108, 107–108 names, 111, 112 in pasting, 206, 207 stairs, 466-467 lighting ceiling fixtures, 431–434, 432–435 ceilings, 443, 443 corridors, 445-446, 446 Line Styles dialog, 569, 569

line weights detail lines, 568-569, 569 working with, 529–531, 530–531 Line Weights dialog, 570, 570 linear arrays, 180–185, 180–184 linear dimensions, 225-227, 226 lines 2D and 3D, 590-593, 591-592 blank drafting views, 574, 574, 577–579 detail, 566-568, 566-568 drains, 292-294, 292-293 filled regions, 543-544 masking regions, 534–535, 534 match adding, 604, 604-605 appearance, 605-606, 606-607 dependent views, 597 summary, 610 radial grid, 366-368, 367 shaft openings, 298-299, 298 sketch, 263 thin, 28-29, 28, 568, 578 winding staircases, 491-493, 491 witness aligned dimensions, 222-223, 222 doors, 94, 94 temporary dimensions, 60, 60, 70 Load Family dialog, hosted families, 39 loading families, 95–96, 95–97 Location Line menu, 12 locking alignments, 193–194, 193–194 dimensions, 240-241, 240-241 orientation, 31, 31

#### Μ

Make Plan View option, 109 Make Wall Bearing button, 379 Manage tab details, 565 elevations, 161 line styles, 569 match lines, 605 object styles, 530, 530 project information, 629, 629 project standards, 411 snaps, 75 temporary dimensions, 61, 62, 93 tile material, 459, 459 masking regions, 534–536, 534–536 match lines adding, 604, 604-605 appearance, 605–606, 606–607 dependent views, 597 summary, 610 Material Browser ceilings, 420-421, 420 floors layers, 275, 275 painting, 289, 290 slabs, 260-261, 261 plywood, 564-565, 564 soffits. 428, 429 materials ceilings, 419-422, 420 floors, 272-273, 272 alternate, 457-461, 457-461 splitting, 283–291, 283–290

goosenecks, 515 soffits, 428, 429 tile, 459-461, 459-461 wrapping by doors, 92, 92 Maximize 3D Extents option, 128, 128 Measure Between Two References button, 71 Measure panel, 58, 58 Medium detail level, 25 medium lines blank drafting views, 574 detail, 566, 566, 568 memory for shadows, 30, 30 men's lavatory, plumbing fixtures for, 435-442, 436-442 metric abbreviations, 14 midpoints for walls, 19 Mirror command, 185–187, 186–188 Mirror-Draw Axis button, 19, 19 Mirror Pick Axis button, 75 mirroring interface for, 19-21, 19-21 objects, 185-187, 186-188 stairs, 497, 498 walls, 75, 75 mitered joins pitched roofs, 327-328, 328 walls, 82, 82 model creation, 45 doors, 90 adding, 90–94, 90–94 wall openings, 98-99, 98-99 interior walls adding, 58-60, 59

temporary dimensions. See temporary dimensions reference planes walls, 49-57, 49-57 working with, 46–48, 47–48 summary, 104 wall joins disallowing, 84-89, 85-89 displaying, 82–83, 83–84 editing, 79-82, 79-82 wall placement, 45–46, 46 windows, 100-103, 100-103 Modify Lighting Fixtures tab, 433 Modify-Place Component tab, 518 Modify Sub Elements button, 314, 314, 316 Modify tab aligning to levels, 279, 280 beams, 380 cabinet alignment, 456 extensions, 202 foundation splitting, 393 Join Geometry option, 392, 392 light fixtures, 444 measurements, 58, 58 offsets, 203, 204 Paint option, 460, 460 rotation, 172 Split Face option, 286, 286, 457, 458 splitting elements, 77, 77 trimming, 200, 201, 575 wall joins, 81, 81, 328 wall-roof joins, 345, 346 modifying, interface for, 19-21, 19-21 mortar joints, 546, 547

mouse, 23
Move command, 166–168, 167–168
Move To: Last option, 177
Move To: Second option, 177
moving

ceiling grids, 412–413, 412–413
dimensions for, 241–244, 242–244
walls, 166–168, 167–168

Multi-Select tab

copying, 206
filters, 284
groups, 581
mirroring, 497
pasting, 206

#### Ν

Name dialog aligned dimensions, 224 view templates, 609 wall openings, 99 names aligned dimensions, 224 bubbles, 364 building sections, 127, 127 levels, 111, 112 printers, 637 rooms, 644, 645 sheets, 614, 615, 631, 632 view templates, 609 wall openings, 99 Navigation bar, 26–28, 26 New Area Plan dialog, 660 New Drafting View dialog, 573, 573 New Family - Select Template File dialog, 42, 42 New Project dialog, 3, 4 project standards, 411 templates, 42, 42 New Schedule dialog, 653 New Sheet dialog, 612–613, 635, 636 notches, 197, 197 notes, 570–572, 571–572 numbering doors, 95 rooms, 644, 646

#### 0

**Object Styles dialog** details, 565, 565 line weights, 530–531, 530 match lines, 606, 606 objects aligning, 188–193, 189–192 displaying, 24–31, 24–31 ghosted, 415 mirroring, 185–187, 186–188 moving with dimensions, 241–244, 242 - 244selecting, 17–18, 17–18 trimming, 200-202, 201-203 Offset command, 203–204, 204–205 offsets lines, 577, 577–578 walls, 53, 53, 203-204, 204-205 opening windows, 34 openings ceilings, 423-425, 424-425

doors, <b>98–99</b> , <i>98–99</i>
shafts, <b>296–300</b> , <i>296–301</i>
Options bar, <b>12</b> , <i>12</i>
aligned dimensions, 214–216, <i>215</i>
arrays, 176, <i>176</i>
blank drafting views, 574–575
columns, 370, <i>370</i>
detail lines, 566
sections, 587
orientation
locking, 31, <i>31</i>
rotating, 171–175, 171–175
origins
detail groups, 581, <i>582</i>
elevation, 33
rotating, 173, <i>173</i>
overhangs, 322, 341, <i>342</i>
overrides
precision, <b>223–225</b> , <i>223–225</i>
text, 244–246, <i>245–247</i>

#### Р

painting floor materials, 286–291, 286–290, 460, 460 panning, 27 paper, 639 parabolic troffers, 443–447, 443–446 parameters Ribbon, 9 sheets, 629–631, 629 partitions, 66–68, 66–69 pasting, 205–208, 206–207 performance, shadows, 30 perspective view for winding staircase, 495-496, 497 Pick Axis button, 64, 64 **Pick Lines** blank drafting views, 574, 575 offsets, 53, 53 Pick Lines button, 52, 53 picking points aligned dimensions, 217–219, 217-220 grids, 357–358, 357–358 piers, 400-402, 400-402 pilasters, 400-402, 400-402 pitched roofs, 319-321, 320-321 adding to corridor, 321-322, 322 attaching to walls, 328, 329 gable ends, 322, 323 joining, 324–327, 324–327 mitered joins, 327-328, 328 plan regions, 330–332, 330–332 trimming, 323–324 pitching floors to drains, 291-294, 291-295 pivot points for arrays, 177, 177 Place Door tab, 39, 92, 95, 95 Place Grid tab, 354 Place Level tab, 108, 109 Place Text tab, 571 Place Wall tab, 22 Plan Region tab, 430 plan regions ceilings, 417–419, 417–418 pitched roofs in, 330–332, 330-332

plans area, 659–662, 659–662 color-fill, 655-657, 656-657 floor, 208-212, 209-211 plumbing fixtures, 435-442, 436-442 plywood settings, 564–565, 564 points aligned dimensions, 217-219, 217-220 blank drafting views, 575, 575 grids, 357-358, 357-358 ramps, 523, 524 repeating details, 537-539, 537 populating sheets, 611-614, 612-614 precision, overriding, 223-225, 223-225 predefined detail components, 532, 533 preview window, 310, 310 previewing files, 37 pitched roofs, 320, 320 roof systems, 310, 310 Print dialog, 637-638, 638 printing, 637-639, 638 profiles stairs, 467-468 walls cuts, 87-89, 87-89 roof attachments, 337-338, 337 sections, 130-134, 130-135 split elements, 194-198, 195-199 Project Browser building sections, 126–127, 126 elevations, 155 groups, 587, 587

levels, 106, 106 overview, 31-33, 32-33 plans, 208 railing systems, 503–506, 503–504 sheets, 612, 612, 614-616, 615 views, 404-405, 404 windows, 33-35, 34-35 project parameters on sheets, 629-631, 629 Project Properties dialog, 630 projects, standards, transferring, 411, 411 Propagate Extents button, 378 properties and Properties dialog AutoCAD files, 589 blank drafting views, 573, 577, 579-581 ceilings, 408, 409, 414-417, 414-416 columns, 371 crop regions, 603, 603 detail sections, 138-139 detailing, 532 dimensions aligned, 223-224 locking, 240 dormers, 349 elevations, 159–161, 160–161 families, 39, 40 filled regions, 547, 553 floors materials, 272, 284 slabs, 256, 257 footing slabs, 398 footings, 394, 395 foundation systems, 388, 388 framing, 376, 376

landings, 512, 513 levels, 116, 116, 121 match lines, 604 overview, 7-9, 8-9 piers, 402 plan regions, 331, 331, 418 plans, 209, 209 ramps, 520, 522, 523, 525 repeating details, 537, 540 Ribbon interface, 7, 7 roofs extrusions, 338-339, 341, 343-344, 344 flat, 304, 305, 307, 310 pitched, 319 sloping, 335–336, 335–336 rooms, 646–651, 647–650 shaft openings, 297-299, 298, 300 sheets, 613, 618, 634, 636, 637 soffits, 430 stairs, 465, 466 custom, 507–508, 507 goosenecks, 513 railings, 473 winding, 491, 493 text, 253-254, 254 troffers, 445 viewports, 624-625, 625 views, 404, 404 walls, 14, 92, 92 constraints, 134, 134 openings, 98–99 sections, 135, 136 windows, 102–104, 102–103

#### Q

Quick Access toolbar, 6, 6

#### R

radial arrays, 175-180, 176-179 radial dimensions, 228-230, 229-230 radial grid lines, 366–368, 367 radial wall elevations, 155 Railing dialog, 471, 471 Railing Type dialog, 524 railings configuring, 470–474, 470–474 extending, 474–479, 474–479 families, 501–502, 501–502 goosenecks, 513-520, 514-520 landings, 479-483, 480-482, 515-516, 516 raised-panel stiles, 517–520, 517–520 systems, 502–507, 503–506 winding staircases, 498–501, 498–501 raised-panel stiles, 517-520, 517-520 RAM for shadows, 30, 30 ramps, adding, 520–526, 521–526 ranges print, 637 view. See view range and View Range dialog Recent Files window, 3, 3 Ref Plane button, 47, 47 reference planes alignment, 189–190, 191 arrays linear, 180–181, 180–181 radial, 176–179, 176, 179

railings, 473-474, 473 roofs extrusions, 340-341, 340, 342 flat, 312, 313 rotating, 171-173, 172 walls adding, 49-54, 49-54 trimming, 54-57, 54-57 working with, 46-48, 47-48 references for match lines, 606-608, 608 regions crop callouts, 144-147, 145-146 dependent views, 598-601, 599-600, 602-603 detail sections, 139-140, 139-140 stretching, 620-621, 620 filled. See filled regions masking, 534-536, 534-536 plan ceilings, 417-419, 417-418 pitched roofs in, 330-332, 330-332 renaming building sections, 127, 127 levels, 111, 112 rooms, 644, 645 sheets, 614, 615 repeating details adding, 536-541, 537-541 filled regions, 554–556, 555–557 Reset Shape tool, 296 Revision Cloud button, 626 revision clouds, 625-628, 626-628 revisions of sheets, 625-628, 626-628

Rewind option, 27 .rfa families, 38-40, 39-41 .rft files, 42-43, 42 Ribbon instance properties, 9, 10 Options bar, 12, 12 overview, 4-5, 4 Properties dialog interface, 7–9, 7–9 type properties, 10–12, 11–13 working with, 5-6, 6 ridges for flat roofs, 311-312, 313 **Rise/Run function** boundaries, 467-468, 467-468 overview, 463-467, 464-466 railings. See railings rods, bracing, 383-387, 384-387 roofs, 303 arcs, 592-593, 592 dormers, 347-352, 348-351 extrusions, 338-347, 339-347 flat creating, 307-310, 308-309 drains, 310-311 overview, 304-307, 305-306 tapering, 310-319, 311-319 levels, 114, 114 pitched. See pitched roofs sloping creating, 332-333, 333-334 slope, 334-336, 335 view range, 336-337, 336-337 walls, 337–338, 337 summary, 352 transparent, 414–415

Room & Area panel, 644–645 room-bounding properties, 650–651, 650 rooms, 641 color-fill plans, 655-657, 656-657 creating, 641–646, 642–646 names, 644, 645 properties, 646-651, 647-650 schedules, 652-655, 653-654 separators, 657–659, 658–659 summary, 663 tags, 644, 651–652, 651–652 unwanted, 655 Rotate command, 171–175, 171–175 rotating ceiling grids, 412, 413 light fixtures, 434, 435 match lines, 607 orientation, 171-175, 171-175 Rounding menu, 224, 225 .rte files, 41-42, 42 .rvt files, 37

#### S

Save As dialog, 36, *36* saving files, **36–37**, *36–37* reminders, 630, *630* scale, changing, 24, *25* Scale tool, 24, *25* Schedule Properties dialog, 653–654, *653* schedules fields, 653, *653* rooms, **652–655**, *653–654* 

sheets, 631-632, 631 sorting, 654 schemes, color, 656-657, 656-657 sconces, corridors, 445-446, 445 Section command, 122, 122 sections building, 121 adding, 122-129, 122-129 modifications, 129–134, 130–135 detail creating, 138-139, 138 crop regions, 139–140, 139–140 splitting section segments, 140–143, 141-142 segment splitting, 140–143, 141–142 for views, 587–588, 588 walls, 135–137, 136–137 Select Items To Copy dialog, 411, 411 Select Levels dialog floor layers, 281 in pasting, 206, 207 Selected Views/Sheets option, 637 selecting objects, 17–18, 17–18 semi-transparent objects, 415 Send To Back button, 550, 551 separating floors, 457-459, 458 separators, rooms, 657-659, 658-659 shading filled regions, 547–552, 547–553 shadows, 30 shafts, elevator footing slabs, 396-398, 397, 399 laying out, 58–60, 59 mirroring, 64–65, 65 openings, 296-300, 296-301

Sheet Issues/Revisions dialog, 627–628, 627 Sheet List Properties dialog, 631, 631 sheets, 611 cover, 631-636, 631-637 creating and populating, 611–614, 612-614 names, 614, 615, 631, 632 organization, 614-619, 615-618 project parameters, 629-631, 629 revisions, 625–628, 626–628 summary, 640 viewports modifying, 619-624, 619-623 properties, 624-625, 625 Shift kev for navigating, 30 unselecting items, 65 shortcuts, keyboard, 35, 35 Show Bubble option, 117 Show Camera option, 151, 151 SHX fonts. 254 sinks lavatory, 441-442, 442 office, 452 size paper, 639 text, 253 Sketch Ceiling button, 423, 423 Sketch mode cut profiles, 89 stairs, 465, 466, 494 sketch options in Draw panel, 12 sketching floor slab, 262 corridor, 266-268, 266-268

picking walls, 262-264, 262-265 trimming, 269-271, 269-270 slabs floor, 255-256 corridor, 266-268, 266-268 creating, 256-261, 256-261 picking walls, 262-264, 262-265 trimming, 269-271, 269-270 footings, 396-400, 396-399 slope dormers, 348-350 pitched roofs, 321-322 sloping roofs, 334-336, 335 Slope Arrow button, 334, 334 slope arrows dormers, 349, 350 sloping roofs, 334-335, 334-335 sloping roofs creating, 332-333, 333-334 slope, 334-336, 335 view range, 336-337, 336-337 walls, 337-338, 337 snaps, 20, 20 finding, 172 intervals, 50 tangent, 23 temporary dimensions, 75–76, 76 wall centers, 172, 358 wall midpoints, 47 soffits, 426-430, 426-430 Sorting/Grouping tab schedules, 654 sheets, 631 sorting schedules, 654

Specify Types dialog, 377 Spindle category, 506, 506 Split Element command, 194–198, 195–199 Split Face button, 286, 286, 457, 458 split lines for drains, 292-293, 292 Split With Gap option, 197 splitting floor materials, 283 alternate, 283-286, 283-285 painting, 286-291, 286-290 roofs, 311-313, 311 section segments, 140-143, 141-142 walls, 77-79, 77-78 spread footings, 400-402, 400-402 stairs, 463 custom, 507-511, 507, 509-511 families, 501-502, 501-502 goosenecks, 513-520, 514-520 landings. See landings mirroring, 497, 498 ramps, 520-526, 521-526 **Rise/Run function** boundaries, 467-468, 467-468 overview, 463-467, 464-466 railings. See railings summary, 526 winding. See winding staircases stalls, lavatory, 438-439, 438-439 standards, transferring, 411, 411 Start-End-Radius Arc option filled regions, 556 interior partitions, 67, 67

landings, 468, 468 mortar joints, 546 radial walls, 51, 51 railings, 483, 483 roof extrusions, 343 roofs, 592, 592 walls, 22, 22 winding staircases, 488, 488 steering wheel, 26-27, 27 stiles, raised-panel, 517-520, 517-520 stretching crop regions, 620-621, 620 views, 601, 601 stringers, 471 structural items, 353 columns, 368-375, 368-375 footings adding, 393-396, 394-395 piers and spread footings, 400–402, 400 - 402slabs, 396-400, 396-399 foundation systems, 387-393, 388-393 framing beam systems, 380-383, 381-382 bracing, 383-387, 384-387 working with, 376-380, 376-380 grids. See grids summary, 406 views, 403-405, 403-405 Structure row for floor slabs, 260–261, 260 sweeps for pitched roofs, 321, 321

Switch Windows menu, 34, 34 switching windows, 34, 34 system families, 37–38

### Т

Tab key filled regions, 584 filters, 423 grips, 222 selections circles, 427 lines, 549, *549* points, 220, 221 walls connecting, 395 filters, 234–236, 234–235 selection, 115, 305 tabs, Ribbon, 4, 4 Tag On Placement button, 90, 91, 92 tags doors, 90, 95 rooms, 644, 651-652, 651-652 tapering flat roofs, 310–319, 311-319 Template File menu, 3 template files, 41-42, 42 templates for views, 609-610, 609 **Temporary Dimension Properties** dialog, 61, 62 temporary dimensions, 60-61 accuracy, 75-76, 76 doors, 93-94, 94

interior walls adding, 72-79, 73-77 corridor, 68-69, 68-69, 71-72, 73-74 lavatories, 70, 70-71 partitions, 66-68, 66-69 settings, 61-65, 62-65 wall splitting, 77-79, 77-78 moving objects, 241-244, 242-244 text. See also annotations leaders adding, 250-251, 250 grips, 244, 244 text, 250-251, 250 notations, 570-572, 571-572 overrides, 244-246, 245-247 overview, 247-250, 248-249 placement, 253 properties, 253-254, 254 summary, 254 thick lines, 577, 578 thickness of floor laver material, 275 thin lines blank drafting views, 578 detail, 568 displaying, 28–29, 28 Thin Lines icon, 28–29, 28 3D lines, **590–593**, *591–592* 3D View, 29-31, 29-31 tile material, 459–461, 459–461 title sheets, 635–636, 636

titles and title blocks
sheets, 616–617, <i>616</i> , 633, <i>6</i> 33
views, 621–623, 622–623
toilets, 438–439, <i>439</i>
tools, <b>165</b>
Align Tool
locking alignments, <b>193–194</b> , <i>193–194</i>
overview, 188–193
Array command, 175
linear arrays, 180–185, <i>180–184</i>
radial arrays, 175–180, <i>176–179</i>
Copy/Paste, 205–208, 206–207
edit commands, 166
Copy, 169–171, 169–170
Move, 166–168, 167–168
Rotate, 171–175, 171–175
Mirror command, 185–187, 186–188
Offset command, 203–204, 204–205
plans, 208–212, <i>209–211</i>
Split Element command, 194–198,
195–199
summary, 212
Trim command, 200–202, <i>201–203</i>
Top Constraint setting, 121
transferring project standards, 411, 411
transparent roofs, 414–415
Trim command, 54–55, <i>54–57</i> , 200–202,
201–203
trimming
blank drafting views, 576–577, 576
floor slab sketches, 269–271, 269–270

objects, 200-202, 201-203 pitched roofs, 323-324, 323 walls, 54-57, 54-57 troffers, 443-447, 443-446 2D lines, 590-593, 591-592 Type Mark property, 103 Type Parameters for viewports, 625 Type Properties dialog aligned dimensions, 223-224, 224 elevations, 161, 162 floor materials, 272, 272 floor slabs, 257, 259 leaders, 251, 252 overview, 10-12, 11-13 railings, 475, 475 ramps, 522, 522 text, 253, 254 windows, 103, 103 Type Selector drop-down, 7–8, 8 typing commands, 35, 35

#### U

unconstraining walls, 238–239, 238–239 units, metric, 14 unselecting items, 65 unwanted rooms, 655 urinals, 440–441, 441 Use Actual Value option, 246, 246 Use Project Settings option, 224 user interface, 2–3, 3–4 existing geometry, 21–24, 22–24 modifying and mirroring, 19-21, 19-21object selection, 17-18, 17-18Ribbon. *See* Ribbon summary, 43 view control and object display, 24-31, 24-31view window, 13-17, 14-16workflow, 4-5, 4-5

#### V

vertical grids, 363-366, 363-366 View Control bar crop regions, 599, 600 tools, 24-26, 25 view range and View Range dialog ceilings, 418, 418 footings, 393-394, 394 framing, 376, 376 offsets, 513 plan regions, 331, 331 sloping roofs, 336-337, 336-337 View/Sheet Set dialog, 638 View-Specific Element Graphics dialog, 414.415 View tab callouts, 143, 143-144 camera views, 149 cut profiles, 87-88, 88 drafting views, 573, 573, 589 elevations, 154, 154 guide grids, 613

keyboard shortcuts, 35 kitchen, 452 match lines, 604, 604 office, 449 options, 26, 26 plan regions, 417, 417 raised panels, 517 roofs extrusions, 339 pitched, 330, 330 sections, 317 schedule properties, 653 sections, 122, 122, 587 sheets, 627 composition, 608 cover, 631, 631 thin lines, 28-29, 28 winding staircase, 495 window switching, 34 View Templates dialog, 609 view window, 13-17, 14-16 ViewCube, 30, 30 viewports modifying, 619-624, 619-623 properties, 624-625, 625 views, 105, 595 activating, 620, 620 blank drafting. See blank drafting views building sections, 121 adding, 122-129, 122-129 modifications in, 129-134, 130-135

callouts, 143-148, 143-148 camera, 149 adding, 149-151, 149-150 modifying, 151-152, 151-152 closing, 34, 34 control, 24-31, 24-31 deactivating, 621 dependent creating, 597-598, 598 crop regions, 598-603, 599-600, 602-603 detail sections, 138-139, 138 crop regions, 139-140, 139-140 splitting section segments, 140–143, 141-142 duplicating, 595-597, 596 elevations annotation properties, 161–163, 162 creating, 152-156, 153-155 interior, 156–159, 156–159 properties, 159-161, 160-161 levels adding, 108-110, 108-110 adjustments, 114-122, 114-122 composition, 110–114, 111–114 creating, 105-108, 107-108 sections adding, 587–588, 588 wall, 135–137, 136–137 stretching, 601, 601

structural, 403–405, *403–405* summary, 163, 610 templates, 609–610, *609* Visibility/Graphics Overrides dialog site components, 597 view templates, 609 visibility of grids, 378 Visual Style button, 29, *29* 

#### W

Wall Sweeps dialog, 321, 321 wall ties, 560-562, 561-562 walls, 45 adding, 49-54, 49-54 angles, 72, 73, 75 cabinets, 455-457, 456-457 ceilings, 409, 409, 415-416 copying, 169-171, 169-170 corridor, 68-69, 68-69, 71-72, 73-74 dimensions aligned, 214-216, 216 as layout tool, 232-237, 233-237 radial, 228-230, 229-230 door openings, 98-99, 98-99 drawing, 13-17, 14-16 elevations, 155 exterior, 45-46, 46 floor slabs, 262-264, 262-265 footing slabs, 396-398, 397

foundation systems, 387–393, 388–393 interior adding, 58-60, 59 temporary dimensions. See temporary dimensions joins disallowing, 84-89, 85-89 displaying, 82-83, 83-84 editing, 79–82, 79–82 justification, 12 levels, 115, 116 midpoints, 19 mirroring, 19-21, 19-21, 75, 75 moving, 166–168, 167–168 offsets, 53, 53, 203-204, 204-205 for roofs extrusions, 338-340, 339, 345, 345-346 pitched, 322-323, 323, 329 sloping, 332–333, 333–334, 337-338, 337 sections adding, 135–137, 136–137 building, 129–134, 130–135 soffits, 426, 426 splitting, 77–79, 77–78 sweeps for pitched roofs, 321, 321 trimming, 54-57, 54-57 unconstraining, 238-239, 238-239 vertical grids, 363-366, 363-366

Walls tab, 19 Warning dialog for pasting, 208,208 wheel button, 23 wide lines, 569, 569 width lines, 13 text, 253 winding staircases, 486 door, 487–488 landing, 486–487, 487 line arrays, 491-492, 491 perspective view, 495-496, 497 railings, 498–501, 498–501 stairs adding, 494-495, 494-495 creating, 488–490, 488–490 mirroring, 497, 498 modeling, 493, 494 windows, 90 adding, 100–103, 100–103 aligning, 188–193, 189–192 arrays, 181-185, 182-184 crossing, 18, 18 mirroring, 185-187, 186-188 Project Browser, 33-35, 34-35 properties, 102-104, 102-103 switching, 34, 34 Windows Explorer, 3 Windows tab. 191

witness lines aligned dimensions, 222–223, 222 doors, 94, 94 temporary dimensions, 60, 60, 70 women's lavatory, 442, 442 Work Plane dialog bracing, 383, 384 lines, 591 raised panels, 518 Work Plane panel, 342, 342 workflow, 4–5, 4–5 wrapping materials by doors, **92**, textual notations, 572, Wrapping At Inserts setting, 92,

# Ζ

ZA command, 17 zooming commands, 17, 27–28, 28 with steering wheel, 27, 27