

Open NDHPlus flowlines and join to table "PlusFlowlineVAA by Reach code. Then join again to table EROM\_MA0001 by COMID. The field Q0001E has mean annual flow (from EROM\_MA0001 table).